

90702

September-24-12 2:18:37 PM

N900040100

Setup Start *NS1*

Stop *NS2*

Start Date: 9/24/12 **Start Qty:** 1.00 ***1***

Cust Item ID:

Required Date: 10/19/12 **Req'd Qty:** 1.00 *** 1 ***

Customer:

Reference:

Approvals: Process Plan: MLJ Date: 12-09-24 Tooling: _____ Date: _____

Run Start *NR1*

QC: _____ Date: _____ SPC (Y/N): _____ Date: _____

Stop *NR2*

[illegible]

Work Order ID 90702

90702

Page 2

September-24-12 2:18:38 PM

Item ID: D350-607-511

Accept

N900040100

Setup Start *NS1*

Revision ID:

Stop *NS2*

Item Name: Quick Release Basket Mounting Installation

Start Date: 9/24/12 Start Qty: 1.00 *1*

Cust Item ID:

Required Date: 10/19/12 Req'd Qty: 1.00 *1*

Customer:

Reference:

Approvals: Process Plan: _____ Date: _____ Tooling: _____ Date: _____

Run Start *NR1*

QC: _____ Date: _____ SPC (Y/N): _____ Date: _____

Stop *NR2*

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

160

0.00

160

Packaging

Packaging

Memo

0.00

Packaging

Identify and pack for shipping as per PPP D350-607-511

Location: 3K412

SL 12/11/12 DAS 201

170

QC21- Final Inspection - Work Order Release

0.00

170

QC

Memo

0.00

Quality Control

12/11/12 MF

12-11-20

Picklist Print

September-24-12 2:18:36 PM

Page 1

Work Order ID: 90702

Parent Item: D350-607-511

Parent Item Name: Quick Release Basket Mounting Installation

Start Date: 9/24/12

Required Date: 10/19/12

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP REV:A NEW ISSUE 10-06-28 JLM VERIFIED BY: LL

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
D39103 Crosstube Lug		Manufactured	No			140	Each	68.0000	4	4			
<div> <div>ST464</div> <div>68</div> <div></div> </div>													
<div> <div>87670</div> <div>36</div> <div></div> </div>													
<div> <div>88547</div> <div>32</div> <div></div> </div>													
D3984 Rubber Extrusion, Crosstube		Manufactured	No			140	f	173.4840	2	2			
<div> <div>ST080</div> <div>173.484</div> <div></div> </div>													
<div> <div>53707</div> <div>173.484</div> <div></div> </div>													
D4148-041 Crosstube Lug Assembly, Fwd		Manufactured	No			140	Each	8.0000	1	1			
<div> <div>ST468</div> <div>8</div> <div></div> </div>													
<div> <div>85752</div> <div>2</div> <div></div> </div>													
<div> <div>87545</div> <div>4</div> <div></div> </div>													
<div> <div>88047</div> <div>2</div> <div></div> </div>													
D4149-041 Crosstube Lug Assembly, Aft		Manufactured	No			140	Each	0.0000	1	1			

SmB

SmB

SmB

SmB

88547

53707

92715

92719

12/11/20

Picklist Print

September-24-12 2:18:37 PM

Page 2

Work Order ID: 90702

Parent Item: D350-607-511

Parent Item Name: Quick Release Basket Mounting Installation

Start Date: 9/24/12

Required Date: 10/19/12

Start Qty: 1.00

Required Qty: 1.00

AN4-14A
Bolt

Purchased No

140 Each 378.0000

16 16
14x 123352

[Handwritten mark]

Location Loc Qty Loc Code

FG 5
122141 5
ST357 373
115374 1
120187 13
121068 17
121708 4
122141 2
122800 250
123021 86

2x 122800

MS21042L4
Nut

Purchased No

140 Each 6,115.0000

16 16
20

[Handwritten mark]

Location Loc Qty Loc Code

314 3085
122452 3085
FP001 3
8182 3
ST300 27
119017 20
121444 7
ST314 3000
123021 3000

123021

NAS1149F0432P
Washer

Purchased No

140 Each 872.0000

32 32
20 12/11/20

[Handwritten mark]

Location Loc Qty Loc Code

275 594
122441 594
ST275 278
121350 15
122151 263

122441

September-24-12 2:18:37 PM

Shop Packet Print

Page 2